



5091/71
190 Tablets

DISHWASHER TABLETS INFORMATION SHEET



190 Tablets

Dishwasher Tablets




DIRECTIONS
Place one tablet directly into the dishwasher dispenser. Greyland Dishwash tablets are designed to fit most dispensers. If the tablet does not fit in dispenser, place in the bottom of the dishwasher.
DO NOT place in the cutlery basket. Select the required dishwashing programme and use the dishwasher as normal.

WASHING TIPS:
Certain items are unsuitable for automatic dishwashers. These include lead crystal, decorated glassware, hand painted china, items with handles of bone, wood, coloured or anodised aluminium and heat sensitive plastic items. Do not let silver touch stainless steel in the dishwasher.

Health and Safety Information

WARNING
Causes serious eye irritation. Contains sodiumbleach. May produce an allergic reaction. Wear eye protection/face protection.
IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
IF eye irritation persists: Get medical advice/attention. Store at temperature not exceeding 40°C.

CONTAINS: Sodium Carbonate - >60%, Sodium Carbonate Peroxide - >30%, Alcohol, C16-18, Ethoxylated - >10%, (1-Hydroxyethylidene) Bisphosphonic Acid, Sodium Salt - >10%, Substitain - <1%.



0 701656 443331
Greyland Ltd • Tameside Park Ind Est • Cheshire • SK16 4PP
Tel: 0161 343 3830 • Fax: 0161 343 9909
www.greyland.co.uk

USE:

- Tough on grease and stains.
- Enzymes for washing efficiently.
- Limescale prevention.
- Built-in rinse aid.
- Surfactants for a powerful clean.
- Fast dissolving.
- Streak free shine.

DIRECTIONS:

- Place one tablet directly into the dishwasher dispenser.
- Greyland Dishwash tablets are designed to fit most dispensers.
- If the tablet does not fit in dispenser, place in the bottom of the dishwasher.
- DO NOT** place in the cutlery basket.
- Select the required dishwashing programme and use the dishwasher as normal.

WASHING TIPS:

- Certain items are unsuitable for automatic dishwashers.
- These include lead crystal, decorated glassware, hand painted china, items with handles of bone, wood, coloured or anodised aluminium and heat sensitive plastic items.
- Do not let silver touch stainless in the dishwasher.

TECHNICAL:

- | | |
|-----------------|-------------------|
| Physical state: | Solid |
| Odour: | characteristic. |
| Solubility: | Soluble in water. |



Greyland Ltd • Tameside Park Ind Est • SK16 4PP
Tel: 0161 343 3830 • www.greyland.co.uk